

08:19

◀ App Store



Log In

Sign Up

12:32



emos



7°C

☰ Excellent

💧 94.0%



All Devices



Room List

Testing

Scenes: 4 | Devices: 26 >



Turn All Off



Turn All On



Edit



Home



Scene



Message



Settings

12:32



emos



Add Device



Create Scene



Add Quick Toggle Card



Scan



7.0

Excellent

94.0%

Testing

Scenes: 4 | Devices: 26



Turn All Off



Turn All On

Edit



Home



Scene



Message



Settings

10:45

41



Add Device



Curtain Module (ZigBee)

Garage module (Wi-Fi)

GoSmart

Lighting



Scene Switch - 1 Button



Scene Switch - 2 Buttons

Cameras and Doorbells

Electrical



Scene Switch - 4 Buttons



Motion (PIR) Sensor IP-2310Z

Energy

Sensors

Garden and Industry



PIR Movement Sensor



Door / Window Sensor IP-2111Z

Gateway Control

Small Home Appliances



Door / Window sensor



ZigBee Extender

Large Home Appliances

Kitchen Appliances

Outdoor Travel



Doorchime white P5735WS



Doorchime silver P5735SS

Exercise and Health

Entertainment



Thermostat underfloor




Thermostat underfloor

Others

10:47



Reset Device



Install the batteries and power on the device

Next

10:48



Reset Device



Hold the RESET button until the LED indicator starts to flash

Back

Next

10:48

41



Reset Device



Confirm the indicator is flashing

Back

Next

10:47 



Adding device...

Keep SMART GATEWAY online.

